

Thermapen ONE Blue Thermometer



The Thermapen ONE Blue combines the latest Bluetooth wireless technology with high accuracy and precision.

The Thermapen ONE Blue is waterproof to IP67. The unit includes a dot matrix display which when paired with a remote device, will show items on the screen alongside the temperature value.

Each item can include a text line with high/low temperature limit that gives the user instant, on-screen pass/fail feedback.

The Thermapen ONE Blue incorporates a reduced tip, stainless steel penetration probe that conveniently folds back through 180° into the side of the instrument when not in use.



Temperature



Bluetooth

Specification

Product Code:	279-607	Battery:	1 x 1.5 volt AAA
Range:	-49.9 to 299.9 °C	Battery life:	500 hours (without backlight)
Resolution:	0.1 °C	Sensor type:	K thermocouple
Accuracy:	±0.3 °C (-19.9 to 119.9 °C) ±0.4 °C (-49.9 to 199.9 °C) otherwise ±1 °C	Dimensions:	19 x 50 x 157 mm
Bluetooth module:	BLE 5.0	Weight:	115 grams